



MICHIGAN SCIENTIFIC
corporation

08500 Ance Rd.
Charlevoix, MI 49720
(231) 547-5511
Fax: (231) 547-7070
<http://www.michsci.com>

Michigan Scientific TR3D- Three Directional Load Cell Series General Use Information

Transducer Configuration

All TR3D series Michigan Scientific Three Directional Load Cells have three separate strain-gage Wheatstone bridges, one for each load channel (X, Y, Z). The four leads (P+,S+,S-,P-) of each bridge are available for the user at the data-acquisition end of the shielded signal cable. We do not recommend sharing power between bridges. Each bridge has been configured and precisely compensated to minimize thermal effects on the output. Each channel is calibrated to full-scale load under controlled load conditions with special fixturing. Complete, NIST traceable calibration reports are provided with each Load Cell.

Channel Cross-Talk

Every Michigan Scientific Three Directional Load Cell is precisely manufactured such that cross-talk between channels is minimized. Cross-talk is output in a given channel that results from loading in a different channel, or even applied loads that aren't measured. All cross-talk is recorded during the calibration process and is included in the calibration reports. The larger cross-talk cases are very linear, and although not necessary, could be corrected for in post-processing for increased accuracy. For most load cases on a given model, the cross-talk from one channel into another is less than 0.5% of full-scale load. The cross-talk for some load cases on certain models can be in the 1.5-1.75% range. Due to these instances, our specification states that the cross-talk between channels will not exceed 2% of the full-scale load.

Moment Loads

One key specification is that the TR3D-A and TR3D-B series Load Cells are not intended to withstand large moment loads. Moment loads have the potential to damage the Load Cell. Even if damage does not occur, moment loads can induce cross-talk into the load channels. Depending on the mounting configuration and moment magnitude, this can approach 5%. Please refer to the documents *TR3D_A_bend_mom_cap.pdf* and *TR3D_B_bend_mom_cap.pdf* for more details, as well as the maximum allowable moment load that can be imparted on these models.

The TR3D-C and TR3D-D series' of Three Directional Load Cells have higher moment carrying capacities than their TR3D-A and TR3D-B counterparts due to their geometry. Consult Michigan Scientific with your specific application if moment loads are a concern.

Applications

Michigan Scientific customers use our Three Directional Load Cells in many different applications. Basically, in any instance that three orthogonal loads are to be measured, a model with the appropriate size and/or load capacity can be adapted. Depending on the circumstances, the height of the Load Cell is not an issue and it can be bolted directly into the customer's



+33 (0)1 46 91 93 32

Capteurs et Systèmes de mesure

59, rue Émile Deschanel - 92400 COURBEVOIE - France - Fax : 33 (0)1 46 91 93 39 - contact@pm-instrumentation.com



fixturing or structure. In other instances, structure or fixturing needs to be modified such that the height of the Load Cell does not significantly alter the primary geometry.

Using Several TR3D- Units in an Array

For some measurement applications, an array of Load Cells, mounted between two stiff fixtures, is more appropriate than using a single Load Cell. Arrays are especially useful when moment loads would be imparted on a single unit. By using an array of Load Cells, then the moment loads are essentially translated into vertical loads at a distance from where the moment is applied to the structure. If the user wishes to know the applied moment, it can be calculated in the post-processing by taking advantage of the known geometry.

Another instance where using an array of Load Cells would be necessary is if the combined loading is larger than the load capacity of a single Load Cell. Load Cells placed in a parallel arrangement have a cumulative load capacity equal to the sum of each Load Cell capacity along a given axis.

TR3D-A or TR3D-B Mounting Configurations

For the following discussion, refer to document TR3D-A_mounting.pdf. In the standard mounting arrangement, a single bolt mounts the top portion of a TR3D-A or TR3D-B model to the fixturing or structure that mates to the top portion of the Load Cell. Four bolts are used to mount the bottom fixturing to the base of the Load Cell. This is the preferred mounting method since the base boundary conditions are well fixed.

In cases where access is not available to mount the Load Cell base with four bolts, an optional Bottom Thread Adapter should be used. This Adapter threads into the base of the Load Cell and “captures” a flat-head socket cap screw. The tightening “key” for this screw is accessed through the top mounting hole of the Load Cell. By tightening this screw first, the Load Cell base is mounted to its mating structure. The top mating structure can now be mounted in the standard configuration. There are two opposing flats on the base of the TR3D-A series load cells that should now be used to index the Load Cell axes to the measurement axes.

TR5D Arrangements

Most TR3D models can be configured as a TR5D unit. This customized configuration adds Mx and My measurement bridges.

Custom TR3D Assemblies

In some instances, a standard TR3D model doesn't quite fit the arrangement, fixturing, capacity requirements or any combination thereof. In many such cases, Michigan Scientific has tailored a standard model to the specific application. Please contact Michigan Scientific with your custom application requirements.